

T12-S6.TB | RM12-S6.TB Quick User Guide

12bay SAS/SATA Enterprise HW RAID Thunderbolt

Content:

- 1) 1x T12-S6.TB or RM12-S6-TB – 12 bay SAS/SATA 6Gb HW RAID Thunderbolt
- 2) 1x Power cable
- 3) 1x Thunderbolt cable
- 4) CD Manual and RAID GUI utility for MAC, Windows, and Linux

Hardware Installation

- 1) Remove the T12/RM12 from its packaging.
- 2) Insert HDD(s) into 12 slots of T12 / RM12
T12 is feature trayless, just simply insert the HDD and close the door where RM12 requires tray, please use included tray to mount the HDD.
- 3) Secure the HDD in to the chassis
- 4) Plug AC cable to unit and turn it ON
- 5) Connect the Thunderbolt cable to the HOST system, by direct to its host or daisy chain from another Thunderbolt device

Configure T12/RM12

Install drivers:

Use included CD or Download from our website.

- Install MCRAID
- Once installed, Open the folder and run HPPT Proxy
- A Browser should pop-up and allow you to configure manage the RAID
- To Login please use:
Login Name: **admin** ; Password: **0000** (four zeros)

For more info RAID modes, Manage and configured – please refer to RAID manual included download is here:
<http://www.datoptic.com/PDF/xx12.S6-TB.RAID.Manual.pdf>

If there is question, problem please contact us:

Email: support@datoptic.com
Telephone: 866 982 3658 or 714 558 1808 (Int'l)
Web Chat: <http://www.datoptic.com/lchat/chat.php>

Please check the product webpage, from time to time to get a new update on firmware, utility and other important improvements.

Thank you for choosing DAT Optic Inc.
DATOptic Team